

Option details

Handy terminal

HT1/HT1-D

This Handy Terminal is a device that can perform any operation such as robot manual operation, point data edit, teaching, and parameter setting, etc.
Has graphic LCD display with backlight for easy viewing.

▼Applicable controllers

TS-S2
TS-SH
TS-X
TS-P

P.626

■ HT1 / HT1-D basic specifications

Name		HT1	HT1-D
External view			
Applicable controllers		TS-S2 / TS-SH / TS-X / TS-P	
Model	Japanese specifications	KCA-M5110-0J(3.5m) KCA-M5110-6J(10m)	KCA-M5110-1J(3.5m) KCA-M5110-7J(10m)
	English specifications	KCA-M5110-0E(3.5m) KCA-M5110-6E(10m)	KCA-M5110-1E(3.5m) KCA-M5110-7E(10m)
Display		Dot matrix monochrome display (with backlighting) 32 characters × 10 lines	
Operation keys		Mechanical switch	
Emergency stop button		Normally closed contact point (with lock function)	
Enable switch		-	3-position
Safety connector		-	15 pin D-sub connector (male)
CE marking		Not supported	Applicable
Operating temperature		0°C to 40°C	
Operating humidity		35% to 85%RH (non-condensing)	
Dimensions		W88 × H191 × D45mm (Emergency stop button not included.)	
Weight		260g (not including cable)	300g (not including cable)
Cable length		3.5m / 10m	

■ Part names and function

Strap holder

Attaching a short strap or necklace strap here prevents dropping the HT1 while operating it or installing it onto equipment.

LCD screen

This is a liquid crystal display (LCD) screen with 32 characters × 10 lines (pixel display), showing the operation menus and various types of information.

Data edit keys

Use these keys to select menus and edit various data.

Connector cable

This cable connects to the controller. One end of this cable is terminated with an 8-pin MD connector (male). Plug this cable into the COM1 connector on the controller front panel.

Emergency stop button

Pressing this button during operation immediately stops robot movement. To release this button, turn it clockwise. Releasing this button also cancels emergency stop.

Run/stop keys

Use these keys to operate the robot for teaching or positioning, or to stop operation. The  and  keys are also provided to move the robot in jog mode.

■ HT1-D rear side

Enable switch (only on HT1-D)

This switch is effective for use with remote safety circuits. This switch cuts off the circuit when pressed or released but allows circuit operation when in the middle position.

Safety connector (only on HT1-D)

Use with remote safety circuits triggered by the emergency stop button or enable switch.